



# Reaction Wheel Application

---

Written by GT-DISC

1. Activity Summary
2. Attitude control overview
3. Human Machine Interface description
4. Application presentation
5. Annex. Encoding Information

# Activity Summary

## Real-time software :


- Methodology
- Specification
- Design
- Programming
- Tests and temporal analysis
- 

*Tool : Xenomai RTOS*

## Control theory :

- Modelling
- Identification
- Control laws synthesis
- Comparative study between model and experiment.

*Tool : Matlab*




Law implementation in the real  
time software

## 2. Attitude control overview

---

- » *Definition*
- » *Objectives of attitude control*
- » *Attitude control actuators*
- » *Example for 3 axis attitude control*
- » *Attitude control subsystem*

# Definition



Every spacecraft needs to carry an Attitude Control System in order to manage the orientation and position during its entire life.

It is a critical system, hence its design and implementation is one of the more importance of a space project.

# Objectives of Attitude Control in Space

- » Attitude modification :
  - ♦ During the life-cycle of the spacecraft, this will adopt different profiles depending on the mission commands, hence re-orienting for each purpose. (antenna directioning, solar pointing, etc)
- » Attitude maintaining with a precision adapted to the mission :
  - ♦ In certain missions, the spacecraft needs high precision attitude in order to correctly performed its scientific endeavour.
- » Cancelling perturbation torques (detumbling, gravity-gradient, atmospheric drag, earth magnetic field, solar pressure, etc).

# Attitude Control Actuators

## » Passive :


- Gravity-gradient Stabilization
- Embedded Magnet

## » Active :


- Magneto torquers
- Reaction Control System (gas thrusters)
- Spin Stabilization
- Control Moment Gyros
- **Reaction Wheel**



Reaction Control System (RCS)




Cubesat Reaction Wheels (x4)




Cubesat Magnetotorques (3-axes)



# Example of 3-axis Attitude Control



Star Tracker System



James Webb Spacecraft Bus (6x Gyros + Reaction Wheels + RCS)

- » A Star tracker for the attitude measurement.
- » 3 gyrometers for the angular speed measurement, and the estimated attitude (angular speed  $> 0.1^\circ/\text{s}$ ).
- » 3 reaction wheels to apply torques to the platform.
- » 3 magneto torquers (used to reduce wheels speed).




# 3. Human Machine Interface (HMI)


---

- » *HMI Overview*
- » *HMI Usage*
- » *Communication Protocol*
- » *Law Selection Overview*


# HMI Overview (1)




# HMI Overview (2)



## » Target Selection




## » Target Connection





To avoid a connection error. The target must be launched before connection

Button

Status




## » Mode selector button






## » Experiment Parameters setting



## » Duration and period

Experiment duration: 30.000 s  
Law activation period: 0.100 s  
Sensors reading period: 0.010 s



The user can adjust by clicking on the values :

- The experiment duration (0.01 to 30 seconds)
- The law activation period (0.01 to 0.5 second)
- The reading sensors period (0.002 to 0.2 second)


## » Law Selection

One of the 8 following laws may be selected:


- **Open loop**
  - Open loop
- **Static gains controled laws**
  - Speed loop
  - Continuous position loop
  - State feedback
  - State feedback with integrator
- **Dynamic laws**
  - Discrete position loop
  - Lead compensator loop
  - Lead lag compensator loop

Area to click for  
law selection

synopsis automatically  
updated after a new law  
selection



# Communication Protocol (1)



# Communication Protocol (2)

## » Type of Messages Sent/Received by the HMI



Message	Request (from Human Interface)	Reply ( from embedded application)
Set experiment parameters	Message ID = 'L' Data = array of 23 reals	Message ID = 'A' Data = Empty
Start experiment	Message ID = 'D' Data = Empty	Message ID = 'A' Data = Empty
Abort experiment	Message ID = 'A' Data = Empty	Message ID = 'A' Data = Empty
Get current sensors values (Initialize)	Message ID = 'C' Data = Empty	Message ID = 'T' Data = array of 4 reals
Get last N sensors values (Running)	Message ID = 'B' Data = Empty	Message ID = 'S' or 'F' Data = n * array of 4 reals

# Communication Protocol (3)

## » Experiment parameters message structure

**Message ID = 'L'**

Array of 20 reals	Set experiment message : data description	Unit
Data[0]	Type of law	NA
Data[1]	Law option	NA
Data[2]	Experiment duration	Millisecond
Data[3]	Law activation period	Millisecond
Data[4]	Reading sensors period	Millisecond
Data[5]	Setpoint type (step / ramp / speed)	NA
Data[6]	Final setpoint value	Radian
Data[7]	Setpoint rise duration	Millisecond
Data[8]	Maximum setpoint speed	Radian/s
Data[9]	Setpoint acceleration	Radian/s <sup>2</sup>
Data[10 .. 20]	Law coefficients	NA

## » Sensors values array structure ( current / last)

	Request (HMI)	Response (embedded computer)
Init :	<b>Message ID = 'C'</b>	<b>Message ID = 'T'</b>
Run :	<b>Message ID = 'B'</b>	<b>Message ID = 'S' or 'F'</b>

Array of 4 reals	Sensors values message : data description	Unit
Data[0]	Motor speed	Radian/s
Data[1]	Platform speed	Radian/s
Data[2]	Platform position	Radian
Data[3]	Motor current	Ampere




# Law Selection Overview

» List of available control laws :

- **Open loop**
  - Open loop
- **Static gains controled laws**
  - Speed loop
  - Continuous position loop
  - State feedback
  - State feedback with integrator
- **Dynamic laws**
  - Discrete position loop
  - Lead compensator loop
  - Lead lag compensator loop

» Setpoint overview :




# Law Selection (1)

## » Open Loop

**Experiment type** Law 0 Open loop

### Synopsis :



**Law Type : 0**

**Setpoint unit:**  
- Amps

**Setpoint type :**  
- Step  
- Ramp


**Law parameters**  
- None

# Law Selection (2)

## » Speed Loop

**Experiment type** Law 1 Speed loop

**Synopsis :**



**Law Type : 10**

**Setpoint unit:**  
- rd/s

**Setpoint type :**  
- Step  
- Ramp


**Law parameters**  
- Kv : LawCoeff[0]

# Law Selection (3)

## » Continuous position Loop

**Experiment type** Law 1 Continuous position loop ▾

**Synopsis :**



**Law Type : 11**

**Setpoint unit:**  
- rd

**Setpoint type :**  
- Step  
- Ramp  
- Profile

**Law parameters :**  
Ki : LawCoeff[0]  
Kp : LawCoeff[1]  
Kv : LawCoeff[2]


**Law option :**  
Integ command  
- Near setpoint  
- Always closed

# Law Selection (4)

## » Discrete position Loop

**Experiment type** Law 1 Discrete position loop ▾

### Synopsis :



**Law Type : 12**

**Setpoint unit:**  
- rd

**Setpoint type :**  
- Step  
- Ramp  
- Profile


**Law parameters**  
A : LawCoeff[0]  
B : LawCoeff[1]  
C : LawCoeff[2]  
Kv : LawCoeff[3]

# Law Selection (5)

## » Lead Compensator Loop

**Experiment type** Law 2 lead compensator loop

**Synopsis :**



**Law Type : 20**

**Setpoint unit:**  
- rd

**Setpoint type :**  
- Step  
- Ramp  
- Profile

**Law parameters :**  
A : LawCoeff[0]  
B : LawCoeff[1]  
C : LawCoeff[2]




# Law Selection (6)

## » Lead-Lag Compensator

**Experiment type** Law 2 lead lag compensatorloop ▾

**Synopsis :**



**Law Type : 21**

**Setpoint unit:**  
- rd


**Setpoint type :**  
- Step  
- Ramp  
- Profile

**Law parameters :**  
A: LawCoeff[0]  
B: LawCoeff[1]  
C: LawCoeff[2]  
D: LawCoeff[3]  
E : LawCoeff[4]

## » State Feedback

**Experiment type** Law 3 State Feedback

**Synopsis :**



**Law Type : 50**

**Setpoint unit:**  
- rd


**Setpoint type :**  
- Step  
- Ramp  
- Profile

**Law parameters :**  
 $Kp$  : LawCoeff[0]  
 $Kv$  : LawCoeff[1]

## » State Feedback with Integrator

**Experiment type** Law 3 State Feedback And Integ ▾

**Synopsis :**



**Law Type :** 51

**Setpoint unit:**  
- rd

**Setpoint type :**  
- Step  
- Ramp  
- Profile


**Law parameters :**  
 $K_i$  : CoeffLaw[0]  
 $K_p$  : CoeffLax[1]  
 $K_v$  : CoeffLaw[2]

## 4. Application Presentation

---


- » *SysML Diagrams Overview*
- » *Dialog Description*
- » *Temporal Constraints*
- » *Synthesis Diagram*

# Requirements Diagram




# State Machine Diagram

Attitude control system.







# User Case Diagram




# Activity Diagram (1)




# Activity Diagram (2)



# Dialog Descript (1)




# Dialog Descript (2)



# Temporal Constraints

Function	Activation	Dead line	WCET ( worst case execution time)
Manage request	Request occurence	100 ms	2ms
Manage duration and period	Period 1ms	1ms	0.2ms
Manage law and setpoint	Period LP (10 to 500 ms)	LP	1ms
Acquire Curves	Period AP (2 to 200 ms)	AP	0.3ms


# Synthesis Diagram



# Architecture Definition

Methodology

Application  
presentation




## Advice for newbies:

For those who have little to none experience in coding, it is recommended to write down the pseudocode before coding your application.




# Annex. Encoding Information

# Hardware Architecture



# Software application description



# Application Software Organization

## Advices :


- 1 file containing all the application tasks.
- Background task : *main* (to complete) containing :

- The declaration and the creation of synchronization elements and tasks communication.
- Initialization of variables.
- Creating and starting the tasks of the application.


- Pending on exitApplication semaphore.

- Stop and destroy the applications tasks.
- The destructions of synchronization elements and tasks communication.

## Architecture summary description :



## Main program :



# HumanMachineInterface\_Task implementation

In file *wheelTasks.c*

```
void HumanMachineInterface_Task()
{
    rt_printf("Starting Human/Machine
              Interface task\r\n");
    ManageRequest();
}

void StartExperiment()
{
    /* Set the Start event here */
}


void AbortExperiment()
{
    /* Set the Abort event here */
}

void ReturnSensorsMeasurement()
{
    (**modify the given answer **)
}
```

In file *wheeHMI.c*


```
void ManageRequest(void) {
    while(ActiveConnection_Flag == true) {
        WaitForMessage(); // Blocking call
        request = ReturnRequest();
        datatype = ReturnDataType();
        switch(request) {
            case 'L': // Set command laws parameters
                if(datatype == REAL_ARRAY_TYPE) {
                    UpdateExperimentParameters(realsArray);
                    WriteResponse('A'); break;
                }
            case 'D':
                StartExperiment(); // Start experiment
                WriteResponse('A'); break;
            case 'A':
                AbortExperiment(); // Abort experiment
                WriteResponse('A'); break;
            case 'C':
                SendPresentSensorsValues(); // Read present
                sensors values
                break;
            case 'B':
                ReturnSensorsMeasurement(); // Read last samples
                block
                break;
        }
    }
}
```

# Sensors/ Actuator Implementation



# Functions to modify

```
void ReturnSensorsMeasurement) {  
    float samplesBlock[50 * 4];  
    char terminatorChar;  
    int i;  
  
    // by default, returns 10 constant samples  
    // ***** Must be replaced *****  
    for (i = 0; i < 10; i++) {  
        samplesBlock[(i * 4)] = 0.1;  
        samplesBlock[(i * 4) + 1] = 0.2;  
        samplesBlock[(i * 4) + 2] = 0.3;  
        samplesBlock[(i * 4) + 3] = 0.4;  
    }  
  
    /* 'S' or 'F' */  
    terminatorChar = 'S'  
    // terminatorChar = 'F' if the experiment is finished  
    writeRealArray(terminatorChar, samplesBlock, 10 * 4);  
}
```





# InitializeExperiment function

## InitializeExperiment :

Declared in file wheelLaws :

```
void initializeExperiment(SampleType sample);
```



The function **sampleAcquisition** must be called before **initializeExperiment**

## Example :

```
SampleType sample;    // Declaration
```

```
SampleAcquisition (&sample); // gets a sample before calling the function  
InitializeExperiment(sample);
```

# ComputeLaw function

**InitializeExperiment :** Must be called to compute a new command (lawPeriod)  
Returns the command in Ampere

Declared in file wheelLaws :

```
float ComputeLaw(SampleType sample);
```



The function **SampleAcquisition** must be called before **ComputeLaw**


To send a command to the motor, the function **ApplySetpointCurrent** must be called after **ComputeLaw**

## Example :


```
SampleType sample;    // Declaration  
float command;
```

```
SampleAcquisition (&sample); // gets a sample before calling the function  
Command = ComputedLaw(sample);  
ApplySetpointCurrent(Command);
```

# Steps to implement the application



# Software application description




Files to modified

Files don't have  
to be modified


F2 has to be called by F1



F2 already called by  
F1



ISAE-SUPAERO



To modify or fill

## **Institut Supérieur de l'Aéronautique et de l'Espace**

10, avenue Edouard Belin – BP 54032  
31055 Toulouse Cedex 4 – France  
T +33 5 61 33 80 80

**[www.isae-supaero.fr](http://www.isae-supaero.fr)**

